

SERIAL COMMS



EUROTHERM
CHESSELL

**180/250mm
Chart recorder**

**Serial
communications
manual**

Communications Manual

List of contents

Section	Page
1 INTRODUCTION	3
2 INSTALLATION	4
2.1 INSTALLATION OF ORIGINAL VERSION (OLDER 250MM RECORDERS ONLY)	4
2.1.1 Mode selection	5
2.2 ISOLATED VERSION INSTALLATION	6
2.2.1 Installation for 250 mm recorders	6
MULTIPOINT RECORDERS	6
CONTINUOUS TRACE RECORDERS	6
2.2.2 Installation for 180 mm recorders	7
2.2.3 Mode selection	9
2.3 COMMUNICATIONS WIRING	9
2.3.1 Original version	9
2.3.2 Isolated version	9
2.3.3 Termination and biasing (not RS232)	11
HOST COMPUTER	11
2.3.4 On-board links	13
2.4 HARDWARE CONFIGURATION	14
2.4.1 Communications parameters	14
2.4.2 Handshake	14
HARDWARE HANDSHAKE	14
SOFTWARE HANDSHAKE	14
3 MODEL 4001 COMMUNICATIONS	15
3.1 COMMUNICATIONS PROTOCOLS	15
3.1.1 ANSI	15
POLLING	15
SELECTION	16
3.1.2 ASCII	16
3.2 PARAMETER ADDRESSING	17
3.3 DATA FORMATS	17
3.3.1 Hexadecimal (Hex)	17
3.3.2 Decimal (Floating point)	17
3.3.3 Character	17

Continued

© 1998 Eurotherm Recorders Ltd.

All rights are strictly reserved. No part of this document may be reproduced, stored in a retrieval system or transmitted in any form, or by any means, without the prior, written, permission of the copyright owner.

Eurotherm recorders Ltd. reserves the right to alter the specification of its products from time to time without prior notice. Although every effort has been made to ensure the accuracy of the information contained herein, it is not warranted or represented by Eurotherm Recorders Ltd. to be a complete or up-to-date description of the product.

List of contents (Cont.)

Section	Page
3.4 MNEMONICS	18
3.4.1 Channel mnemonics	19
INPUT CHANNELS	20
OUTPUT CHANNELS	22
DERIVED CHANNELS	24
3.4.2 Alarm mnemonics	25
ALARM BUFFER VALIDATION CHECKS	25
3.4.3 Instrument mnemonics	27
3.5 COMMAND MNEMONICS	31
3.5.1 Alarm acknowledge (AA)	31
3.5.2 Printer on (CG)	31
3.5.3 Chart halt (CH)	31
3.5.4 Printer off (CO)	31
3.5.5 Chart Wind (CW)	31
3.5.6 Data Dump (DD)	31
3.5.7 Disable program mode (DP)	31
3.5.8 Enter alarm data (EA)	31
3.5.9 Enter channel data (EC)	31
3.5.10 Enable program mode (EP)	31
3.5.11 Get indicated alarm data (GA)	32
NO MATHS PACK FITTED	32
MATHS PACK FITTED	32
3.5.12 Get free alarm (GF)	32
3.5.13 Chart rewind (CR)	32
3.6 PARAMETER SCROLLING	33
3.6.1 Block parameters	33
3.6.2 Scroll parameters	33
ALARM PARAMETERS	33
INSTRUMENT PARAMETERS	33
3.7 CHARACTER SET	34
3.8 APPLICATION NOTES	40
3.8.1 Message timing	40
3.8.2 Command mnemonics	40
3.8.3 Channel selection	40
3.8.4 Alarm selection / polling	40
SELECTION	40
3.8.5 Printed text	40
3.8.6 Special characters	41
ASCII MODE	41
ANSI MODE	41
3.8.7 Multi-parameter data packets	41
3.8.8 Digital input channels	41
3.8.9 Floating point overflow	41
4 GOULD MODICON MODBUS PROTOCOL	42
4.1 CHANNEL ADDRESSING	42
4.2 READING ANALOGUE VALUES	42
4.2.1 16-bit format	42
4.2.2 32-bit format	43
EXAMPLE 1 READ CHANNEL 05	43
TOTALISER VALUES	43
4.3 FUNCTION CODES	44
5 XMODEM TRANSFER	46
6 LIST OF EFFECTIVE PAGES	47
INDEX	48

COMMUNICATIONS

1 INTRODUCTION

This manual is intended as an aid to those involved in the installation and operation of a serial communications link between one or more chart recorders (or I/O racks) and a host computer.

Section 2 describes the physical installation of a communications option and its hardware set-up and wiring.

Section 3 describes host communications protocol emulation of the 4001 communications protocol allowing customers with model 4001 recorders to transfer their communications programs to more modern recorders without difficulty.

Section 4 deals with the Gould Modicon Modbus RTU protocol.

Section 5 gives a procedure for XMODEM file transfers, for saving and restoring recorder configurations.

2 INSTALLATION

The communications option is in two versions. The original version has a 25-way D-type connector, whilst the newer (isolated) version has two 9-way D-type connectors - one plug; one socket. Before installation is carried out, it is recommended that the links on the circuit board be checked against figure 2.3.4 to ensure correct positioning.

2.1 INSTALLATION OF ORIGINAL VERSION (OLDER 250MM RECORDERS ONLY)

This section describes the installation of the communication option in the box located at the rear of the recorder. For those recorders already fitted with the option, this section may be ignored.

CAUTION

THE CIRCUIT BOARD INCLUDED AS A PART OF THE KIT CONTAINS COMPONENTS WHICH ARE SENSITIVE TO STATIC ELECTRICAL DISCHARGE. ALL RELEVANT PERSONNEL SHOULD BE AWARE OF STATIC HANDLING PROCEDURES. IF IN DOUBT, CONSULT THE RELEVANT SECTIONS OF EITHER THE INSTALLATION AND OPERATION MANUAL OR OF THE TECHNICAL MANUAL.

The communications option kit consists of a circuit board, two screws and two labels. The installation procedure is as follows. Reference should be made to figures 2.1a and 2.1b as required.

- a. Remove the battery cover, retaining it and its securing screws for later re-assembly.
- b. Remove the communications box by removing the two securing nuts. Retain these nuts and their associated shake-proof washers for use in re-assembly.
- c. Knock out the three slots in the box.
- d. Fit the labels supplied
- e. After taking precautions against static discharge, screw the circuit board to the box.
- f. Plug the assembled box into the connector at the rear of the recorder.
- g. Fix the box to the recorder using the nuts and shake-proof washers previously removed.
- h. Refit the battery cover.
- i. Select RS232 or RS422/485 (section 2.1.1 below), then carry out an autoconfigure as described in the installation and operation manual supplied with the recorder.




Figure 2.1a Battery cover and communications box location

2.1 INSTALLATION OF ORIGINAL VERSION (Cont.)




Figure 2.1b Communications option assembly

2.1.1 Mode selection




Figure 2.1.1 Communications set-up switches

The communications can be set to RS232 or RS422/RS485 by sliding all the elements of the DIL switch to the right (RS232) or to the left (RS422/485).

In RS232 mode, the LEDs show their stated functions. The LEDs are off when the relevant lines are idle, and are illuminated when they are active.

In RS422/485 mode, only the transmit (Tx) and receive (Rx) LEDs are operative. These LEDs are off when the lines are at idle, and are illuminated when they are active.

The pin allocations for RS422/485 and RS232 are shown in section 2.3.1 below.

Note: Four wire (TXA/B, RXA/B) RS485 is supported; two wire RS485 is not supported.

2.2 ISOLATED VERSION INSTALLATION

2.2.1 Installation for 250 mm recorders

MULTIPOINT RECORDERS

With the recorder isolated from hazardous voltages, remove the battery cover and dummy comms box (if fitted) as described in section 2.1 instructions 'a' and 'b'. Fit the comms module supplied with the kit, ensuring that the connector is correctly mated before tightening the fixings and replacing the battery cover.

Re-apply power to the recorder, switch on and carry out an Autoconfigure, as described in the installation and operation manual supplied with the recorder.

CONTINUOUS TRACE RECORDERS

With the recorder isolated from hazardous voltages, take the ribbon cable supplied with the kit, and plug it into the header on the comms module circuit board.

Pass the ribbon cable through the slot in the rear of the recorder, then secure the comms module to the recorder using two nuts.

Open the recorder door and release the writing system by undoing the two captive screws (fig 2.2.1a)

Pull the writing system forwards until access can be gained to the control board mounted at the rear.

Plug the free end of the ribbon cable into CON 3 on the control board (figure 2.2.1b).

Return the writing system to the case and secure it, using the two captive screws.

Set the comms module to RS232 or RS422/485 as described in section 2.2.3.

Re-apply power to the recorder, switch on and carry out an Autoconfigure, as described in the installation and operation manual supplied with the recorder.




Figure 2.2.1a Writing system securing screws




Figure 2.2.1b Communications connector location

2.2.2 Installation for 180 mm recorders

CAUTION

THIS UPGRADE INVOLVES THE HANDLING OF COMPONENTS WHICH ARE SENSITIVE TO STATIC ELECTRICAL DISCHARGE. ALL RELEVANT PERSONNEL MUST BE AWARE OF STATIC HANDLING PROCEDURES. IF IN DOUBT, REFERENCE SHOULD BE MADE TO THE INSTALLATION AND OPERATION MANUAL OR THE TECHNICAL MANUAL.

1. Isolate the recorder from all high voltage sources (both supply and signal)
2. Open the recorder door (by lifting the bottom of the catch, and then turning it clockwise) For convenience, remove the chart and print cartridge.
3. With the cassette open, Release the writing system by undoing the captive screws ('A' in figure 2.2.2a)
4. Pull the writing system forwards until it reaches its stops.
5. Lift the writing system out of the case, releasing the various connectors as they become accessible (figure 2.2.2b).
6. Release the Power supply unit from the front, using screws 'B' in figure 2.2.2b, then from the back, by removing the safety earth (nut 'C' in figure 2.2.2c) and securing screw 'D'.




Figure 2.2.2a
Writing system securing screws




Figure 2.2.2b Writing system removal
and PSU securing screw locations




Figure 2.2.2c
PSU release (rear view)

7. Disconnect the battery pack as shown in figure 2.2.2d
8. Rotate and lift out the power supply as shown in figure 2.2.2e, carefully avoiding damage to the battery pack connector.




Figure 2.2.2d Battery pack disconnection




Figure 2.2.2e PSU removal

2.2.2 INSTALLATION FOR 180mm RECORDERS (Cont.)

9. Fit the plastic cable clip as shown in figure 2.2.2f.
10. At the rear of the recorder, remove the blanking plate, and fit the communications module (figure 2.2.2g).
11. Feed the communications module ribbon cable across the inside back of the recorder, secure it with the clip, then fold the cable back on itself and make a right angle turn upwards (figure 2.2.2f).
12. Re-fit the power supply unit, and ensuring that the battery pack connector is passed through its aperture, secure it at the front and at the back, using the four screws and safety earth nut previously removed. **ENSURE THAT THE SAFETY EARTH IS SECURELY TERMINATED.**
13. Return the writing system to the case, ensuring all the connectors are re-made.
14. Re-apply power to the recorder, and carryout an Autoconfigure as described in the Installation and Operation manual supplied with the recorder.




Figure 2.2.2f Cable clip location




Figure 2.2.2g Comms module fitting




Figure 2.2.2h Routing cables and returning the PSU




Figure 2.2.2i Communications connector location

2.2.3 Mode selection

Once physical installation is complete, the communications mode should be set up as RS232 (Single drop) or RS422/RS485 (Multiple drop) before electrical connections are made.

The selection of communications mode is made by setting ALL of the switches located between the two 9-way D-types up for RS232 or down for RS422/485*, as shown on the communications module label.

* The module is mounted 'sideways' on Graphics Display Units. The switches should be set left for RS232 or right for RS422/485.




Figure 2.2.3 Set-up switch locations (isolated version)

2.3 COMMUNICATIONS WIRING

2.3.1 Original version

The serial link is implemented using a 25-way D-type (fixed socket) connector. Table 2.3 gives pin-out information for RS232C and for RS422/485. Recorder Tx should be connected to the host Rx and *vice-versa*.

2.3.2 Isolated version

Tx should be connected to Rx at the host and vice-versa.



The serial link is implemented using two 9-way D-type connectors. For non-graphics instruments set to RS422/485, the two connectors are wired in parallel for easy 'daisy-chaining' in multi-drop applications. For non-graphics instruments set to RS232, and for all data acquisition racks, only the 'male' connector (plug) is to be used.

See the graphics unit manual for graphics recorders/display units details.

Note: The signal ground MUST be earthed at one point (only) in the link.

2.3 COMMUNICATIONS WIRING (Cont.)

Isolated Comms
(2 x 9-way D-types)

Pin	Function	Pin	Function
1	 5V	1	 5V
2	RX	2	TXA
3	TX	3	TXB
4	DTR	4	Not connected
5	Signal ground	5	Signal ground
6	DSR	6	Not connected
7	RTS	7	RXB
8	CTS	8	RXA
9	Not connected	9	Not connected

RS232 Pin out
(Switches up)
(Fixed plug only)

RS422/485 Pin out
(Switches down)
(Plug or socket)

Comms pinouts for current recorders and I/O (data acquisition) racks.
(I/O racks may use only the fixed male connector (plug) for the serial link)

RS232 Terminations

5v*	Rx	Tx	DTR	0V	DSR	RTS	CTS
-----	----	----	-----	----	-----	-----	-----

RS232 available with upper connector only (all switches left)



RS422/485 Terminations

5v*	TxA	TxB	NC	0V	NC	RxB	RxA
-----	-----	-----	----	----	----	-----	-----

Lower connector always RS422/485.
Upper connector selectable RS232 (all switches left) or RS424/485 (all switches right)

Comms pinouts for Graphics Display Units

Non-Isolated Comms
(25-way D-type)

Pin	Function	Pin	Function
1	Protective ground	1	Protective ground
2	TX	2	TXB
3	RX	3	TXA
4	RTS	4	RXB
5	CTS	5	RXA
6	DSR	6	Not connected
7	Signal ground	7	Signal ground
19	 5V	19	 5V
20	DTR	20	Not connected

RS232 Pin out
(Switches right)

RS422/485 Pin out
(Switches left)

Comms pinouts for previous recorder versions

Table 2.3 Communications module pinouts

2.3.3 Termination and biasing (not RS232)

If the communications line is left open-ended, the end of the cable acts as a reflector, returning what can appear to be 'true' data signals back down the line. A receiver cannot distinguish between 'true' and reflected data, with the result that the 'true' data is corrupted.

In order to avoid this, a termination resistor is fitted across the line at the final instrument. If the value of this resistor is equal to the characteristic impedance of the cable (120 Ohms in this case), then the line appears to be of infinite length and no reflections occur. Such a value however, does not give the best signal-to-noise ratio, so a compromise value (220 Ohms) is chosen to give the optimum performance in reducing unwanted reflections and in improving the signal-to-noise ratio.

The recorder communications port is terminated as shown in figure 2.3.3a, below. In a single point-to-point application, it may be necessary to terminate the instrument with a 220Ω resistor. In multi-drop systems, only the final unit should be terminated in this way, otherwise the transmitted signal levels may be reduced to an unacceptable level.




Figure 2.3.3a System termination and biasing

HOST COMPUTER

When not communicating, the instrument outputs go to a high-impedance state to allow multi-drop connection. This will cause a problem if the host computer is not fitted with biasing resistors to pull these essentially open circuit lines to their idle states as defined for the RS422/RS485 standards. To overcome such problems, external biasing resistors can be fitted as shown in figure 2.3.3b (a) below.

With long cable runs it may also be necessary to terminate the transmission line. Figure 2.3.3b (b) shows how this may be done using external biasing resistors. Such a circuit is for use where the host receiver does not have its own internal biasing arrangements. Where the host does have its own internal biasing, the fitting of a 220Ω resistor across the receive inputs (figure 2.3.3b (c)) will terminate the line correctly.

2.3.3 TERMINATION AND BIASSING (Cont.)




Figure 2.3.3b Host computer termination and biasing

2.3.4 On-board links

When retro-fitting or replacing a communications board, a number of links need to be correctly set. The positions of these links depends on the model as shown in the sketches below. The sketches show an issue 2 board. Issue 1 boards are similar, but do not have links at 'A'. This is important only for I/O rack users.

The communications link is set to RS232 by setting all the toggle switches up (as shown in the figures) or to RS422/485 by setting all the switches down.




Figure 2.3.4 Communications board link positions

2.4 HARDWARE CONFIGURATION




Figure 2.4 Communications configuration

2.4.1 Communications parameters

Protocol	4001 ANSI* 4001 ASCII*	Uses ASCII codes, including control codes (e.g. STX) Uses ASCII codes, but control codes are replaced by printing characters (See section 3.1.2 below).
Baud Rate	MODBUS 110 to 19,200	RTU protocol. Fixed data bits = 8; No handshake. Scrollable 19,200, 9,600, 4,800, 2,400 1,200, 600, 300, 110
Parity	Odd, even, none	Allows parity to be set.
Data Bits	7, 8	Eight bits required for 'special' characters Hex 80 to E2 in table 3.7.
Stop bits	1, 2	Allows the number of stop bits to be set.
H/W Handshake	On/Off	Enables / Disables handshake.
Group Address	0 to 7	Group address (G) used as a part of the 4001 channel address.
Address	1 to 247	Gould Modicon address

* 4001 ASCII and 4001 ANSI protocols may not be applicable to all recorder models.

2.4.2 Handshake

Handshake is not applicable to MODBUS protocol.

HARDWARE HANDSHAKE

Hardware handshake operates with three signals CTS, RTS and DTR. DSR is ignored by the recorder.

When hardware handshake is 'ON', DTR and RTS outputs are set to their 'ON' condition (voltage +ve) when the instrument is capable of communication. These signals will therefore be off during power up / initialisation etc. The CTS input high to the instrument enables its transmitter.

When hardware handshake is set 'OFF' DTR and RTS are set to their OFF states (voltage -ve). The CTS input is ignored.

SOFTWARE HANDSHAKE

XON/XOFF handshaking is implemented in ASCII mode only (section 3.1.2). On receipt of XOFF (ASCII hex 13) the recorder will stop transmitting at the end of the current character, and will not re-start transmission until it receives XON (ASCII hex 11). All bytes received between XOFF and XON are ignored. Multiple XONs are ignored. The instrument does not generate XON or XOFF.

3 MODEL 4001 COMMUNICATIONS

Note: 4001 communications protocols may not be available on all Models.

3.1 COMMUNICATIONS PROTOCOLS

3.1.1 ANSI

This is an implementation of the ANSI standard ANSI - X3.28 - 2.5 - A4 and specifies two modes: POLLING (for reading values from an instrument), and SELECTING (for writing values to an instrument).

POLLING

The sequence of bytes sent to the instrument in order to read a value is:

<EOT>[G][G][U][U][CA][C1][C2]<ENQ>

Where:

- G is the Group Address set up in the communications configuration.
- U is a 'Logical Unit' number, associated with up to eight channel addresses.
- CA is a channel address within the logical unit.
- C1C2 is the two character mnemonic which defines the parameter to be read.

See table 3.2 for U and CA allocations, and tables 3.4.1, 3.4.2 and 3.4.3 for a mnemonic / parameter cross reference.

In response to such a polling message, the instrument will reply with one of the following:

POLL COMPLETE MESSAGE

<STX> [CA] [C1] [C2] [D1] [D2 DN] <ETX> [BCC]

Where D1 to DN is the N byte value of the polled parameter. The number of bytes required is a function of the particular parameter polled. BCC is a block check control character which is the result of exclusive ORing bytes [CA] to <ETX> inclusive. After a POLL COMPLETE message, the host can respond with <NAK> (which causes re-transmission of the parameter previously polled), <ACK> (which polls the next parameter in the poll list (see section 3.6)), or with a complete new polling message.

POLL INCOMPLETE MESSAGE

<STX> [CA] [C1] [C2] <EOT>

This indicates that there was an error in the polling message. The host must send a complete new polling message in order to access the parameter (i.e. sending <ACK> or <NAK> does not have any effect).

NO RESPONSE

The polling message was not recognised.

3.1 COMMUNICATIONS PROTOCOL (Cont.)

SELECTION

The sequence of bytes sent to the instrument in order to write a value to a parameter is:

```
<EOT>[G][G][U][U]<STX>[CA][C1][C2][D1][D2...DN]<ETX><BCC>
```

Where:

- G is the Group Address set up in the communications configuration.
- U is a 'Logical Unit' number, associated with up to eight channel addresses.
- CA is a channel address within the logical unit.
- C1C2 is the two character mnemonic which defines the parameter to be read.
- D1 to DN is the N-byte value to be written to the parameter.
- BCC is a block check character calculated by exclusive ORing bytes CA to ETX inclusive.

See table 3.2 for U and CA allocations for current recorders and tables 3.4.1, 3.4.2 and 3.4.3 for a mnemonic / parameter cross reference.

In response to such a selection message, the instrument will reply with one of the following:

SELECTION COMPLETE MESSAGE

The instrument responds with a single <ACK>. The host may now re-enter the selection procedure after <STX> and write a new [CA] to <BCC> message, providing that the new parameter is in the same logical unit as the last one (i.e. [G] and [U] are the same). Alternatively, the host can send a complete new selection message.

SELECTION INCOMPLETE MESSAGE

The instrument responds with a single <NAK>, indicating that there was an error in the selection message. The host must send a complete new selection message (i.e. it may not re-enter after STX)

NO RESPONSE

The selection message was not recognised.

3.1.2 ASCII

This mode is intended for use with simple micros, or 'dumb' terminals, which are unable to transmit ASCII control characters and / or having no hardware handshake. The non-printing control codes are replaced with 'printing' characters as shown in table 3.1.2 below. BCC is omitted, since it might easily be one of the control codes 22 to 26 or 28. XON/XOFF handshaking is supported. In all other respects, the protocol is the same as the ANSI mode, described above.

Control character definition	ANSI standard character	Hex code	Printing character	Hex code
Start of text	STX	2	"	22
End of text	ETX	3	#	23
End of transmission	EOT	4	\$	24
Enquiry	ENQ	5	%	25
Acknowledge	ACK	6	&	26
Negative acknowledge	NAK	15	(28

Table 3.1.2 Printing and non-printing codes

3.2 PARAMETER ADDRESSING

The protocol uses a three element address: Group Address (G) (0 to 7), set up in the communications configuration to identify one of up to eight recorders on a multi-drop link; Logical Unit Address (U) and Channel Address (CA). The recorder can have up to 16 logical units (LUs) associated with it according to the model number. LU 0 is used to access instrument, alarm and control mnemonics. In such cases, the channel address is irrelevant, but a valid CA (0 to F) must still be included in the polling/selecting messages.

As can be seen from table 3.2 below, logical units can have up to 16 associated channel addresses (CAs). For example, to access Measuring Channel 28, the logical unit address (U) would be 7, and CA would be 3. To access Derived Channel 28, the LU address would be 'C' and the CA would be 3.

		LOGICAL UNIT ADDRESS (U)															
		1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
CHANNEL ADDRESS (CA)	0	1	5	9	13	17	21	25	29	D1	D9	D17	D25	D65	D73	D81	
	1	2	6	10	14	18	22	26	30	D2	D10	D18	D26	D66	D74	D82	
	2	3	7	11	15	19	23	27	31	D3	D11	D19	D27	D67	D75	D83	
	3	4	8	12	16	20	24	28	32	D4	D12	D20	D28	D68	D76	D84	
	4	33	36	39	42	45	48	51	54	D5	D13	D21	D29	D69	D77	D85	
	5	34	37	40	43	46	49	52	55	D6	D14	D22	D30	D70	D78	D86	
	6	35	38	41	44	47	50	53	56	D7	D15	D23	D31	D71	D79	D87	
	7	57	66	75	84	93	D8	D16	D24	D32	D72	D80	D88				
	8	58	67	76	85	94	D33	D41	D49	D57	D89	D97					
	9	59	68	77	86	95	D34	D42	D50	D58	D90	D98					
	A	60	69	78	87	96	D35	D43	D51	D59	D91	D99					
	B	61	70	79	88	D36	D44	D52	D60	D92							
	C	62	71	80	89	D37	D45	D53	D61	D93							
	D	63	72	81	90	D38	D46	D54	D62	D94							
	E	64	73	82	91	D39	D47	D55	D63	D95							
	F	65	74	83	92	D40	D48	D56	D64	D96							

Table 3.2 Logical unit and channel addresses

3.3 DATA FORMATS

Current recorder protocol specifies a variable number of data bytes, according to the parameter being accessed. Three basic formats are used:

3.3.1 Hexadecimal (Hex)

Five data bytes are transmitted in the form >HHHH where > must always be present, followed by four hex bytes (H in the example). The data transferred may represent a single parameter, or a group of parameter values packed into a 16-bit word and then Hex encoded.

3.3.2 Decimal (Floating point)

Five data bytes are transmitted in on of the following formats according to decimal point position and whether the value is positive (use decimal point) or negative (use – sign).

DDDD.	DDDD-
DDD.D	DDD-D
DD.DD	DD-DD
D.DDD	D-DDD
.DDDD	-DDDD

3.3.3 Character

A string of hex data bytes, the number of bytes being defined for each relevant parameter.

3.4 MNEMONICS

The tables which follow, give an alphabetic list of mnemonics with definitions, formats etc. in the following groups. All mnemonics must be in CAPITAL letters. 4001 mnemonics which are not emulated are not included in the tables. In such cases, selection will be ignored, and polling will always return the value 0.

Channel mnemonics (see table 3.4.1)	
CF	Channel flags *
CJ	External CJ temperature.
DH	Output signal high value.
DL	Output signal low value.
EU	Engineering units and print zone.
FH	Function high value.
FL	Function low value.
IL	Input signal low value.
IH	Input signal high value.
LG	Legend string.
LN	Legend number.
MV	Measured value in hex.
NA	Number of alarms assigned.
OC	Constant output value
OF	Offset value
OH	Scale high value.
OL	Scale low value.
OS	Output source configuration [†]
PV	Process variable (Measured value scaled to engineering units).
SH	Shunt value.
ST	Channel status.

* Channel Flags are:	
CJ type	Scale print enable
Function engineering units	Scale type
Interpolation enable	Trace skip
Linearisation (function) type	Output type

† Output source configuration contents:	
Error drive	Source Channel number
Source type	Value format

Alarm mnemonics (see table 3.4.2)	
A1	Alarm type, hysteresis, average.
A2	Alarm sense, alarm status, rate-of-change alarm period.
A3	Set point as a proportion of channel scale.
A4	Deviation, rate-of-change change value.

Instrument mnemonics (see table 3.4.3)	
BN	Batch number
CS	Chart speeds A and B (See also IF)
DY	Day number
ER	Serial link communications errors
HR	Hours
IF	Instrument flags (Current chart speed, Date format, Internal CJ units)
II	Instrument identifier
IS	Instrument alarm and printer on/off-line flags
L1/2/3	User linearisation tables
MI	(Not M1) Minutes
MO	Month number
M2/3	Mode 2(3) log interval A
PM	Print mode

(Continued)

Instrument mnemonics (continued)

PT	Text string to be printed
RJ	Remote CJ mode (Software versions 3.12 onwards)
SC	Slot configuration
SE	Seconds
T0	Single Remote CJ configuration (Software versions 3.12 onwards)
T1 to Tn	Multiple remote CJ configurations for input boards 1 to n (Software versions 3.12 onwards)
VN	Communications software version number
XT	Enter XModem mode
XE	Modem error code
YR	Year

3.4.1 Channel mnemonics

NOTES:

- 1) Channel parameter updates are loaded into a buffer, until an EC mnemonic is received. The checks listed below are then carried out, and if the update is valid, it is loaded into the recorder's data base and an ACK is returned. If the update is not valid, the buffer content is discarded and a NAK is returned.
 - a) $OL \neq OH$
 - b) $IL < IH$
 - c) $FL < FH$
 - d) Linearisation type is valid for the input type.
 - e) Output channel is fitted
 - f) Output channel source exists.
 - g) 4-digit value format selected for constant output channel
 - h) $DL < DH$
 - i) Output channel constant ≥ 0

 - 2) Further checks are carried out as a background task. This means that an 'ACK' may be returned, as described above, even if one of these checks (listed below) fails, causing the channel not to measure. It is recommended therefore, that a read of channel status (ST -ref. table 3.4.1) is made, 10 seconds (minimum) after an EC has been written, to establish that all the checks have passed. The background checks are as follows:
 - a) Linearisation limits are not exceeded .
 - b) External cold-junction lies within the linearisation limits.
 - c) Maximum input range is not exceeded.
-

3.4.1 CHANNEL MNEMONICS (Cont.)

Input channels

Mnemonic	Format	Bits	Definition	Permission wrt host
CF	Hex	0	CHANNEL FLAGS SCALE PRINT FLAG Select: Sets scale type A off (0) or automatic (1) Poll: 0 = Scale type A off; 1 = Auto or customised	R/W
		1	Not used	
		2	TRACE SKIP FLAG Select: 0 = Trace on; 1 = Trace off Poll: 0 = Trace on or conditional; 1 = Trace off	R/W
		3	INTERPOLATION ENABLE (1 = on; 0 = off)	R/W
		4 & 5	Not used	
		6 & 7	COLD JUNCTION TYPE 0 = Off 1 = Internal 2 = External 3 = Remote	R/W
		8 to 11	LINEARISATION TYPE 0 = Thermocouple type B 1 = Thermocouple type E 2 = Thermocouple type J 3 = Thermocouple type K 4 = Thermocouple type R 5 = Thermocouple type S 6 = Thermocouple type T 7 = Pt100 (100Ω platinum resistance thermometer) 8 = mV (Square root extraction) 9 = Volts / linear A = mv (linear) B = Input type = comms. C = Input type = Off D to F = User linearisation tables 1 to 3 respectively	R/W
		12 & 13	LINEARISATION TYPE ENGINEERING UNITS 0 = Degrees Celsius (°C displayed) 1 = Degrees Fahrenheit (°F displayed) 2 = Kelvins (K displayed) 3 = Rankine (R displayed)	R/W
		14 & 15	Not used	
		CJ	Hex	0 TO 15
EU	Hex	0 to 3	ENGINEERING UNITS AND PRINT ZONE PRINT ZONE A Integer 0 to 9. When polled, returns 0. 0 = 0 to 100% 5 = 50 to 100% 1 = 0 to 75% 6 = 0 to 25% 2 = 25 to 100% 7 = 25 to 50% 3 = 0 to 50% 8 = 50 to 75% 4 = 25 to 75% 9 = 75 to 100%	
		4 to 7	INPUT SIGNAL UNITS Select: Ignored Poll: Returns 0	R/W
		8 to 11	SCALE UNITS Ignored unless value is hex C, in which case the units string is cleared. Always returns 0.	R/W
		12 to 15	Not used. Always returns 8	

For software versions prior to 3.12, Bits 6/7 are defined as follows:
0 = Off, 1 = Internal,
2 = External (if polling, 2 = External or Remote)

Software version 3.17 onwards.
Should the print area be more than 1% different from any of these zone limits, zone 0 is returned.
E.G. 24 to 76% would be returned as zone 4, but 23 to 76% would be returned as zone 0.

Table 3.4.1a Input channel mnemonics (sheet 1)

3.4.1 CHANNEL MNEMONICS (Cont.)

Mnemonic	Format	Bits	Definition	Permission wrt host
FH	Decimal	N/A	FUNCTION HIGH VALUE	R/W
FL	Decimal	N/A	FUNCTION LOW VALUE	R/W
IH	Decimal	N/A	INPUT HIGH VALUE	R/W
IL	Decimal	N/A	INPUT LOW VALUE	R/W
LG	Character	N/A	CHANNEL LEGEND 18-character string = 1st 18 characters of channel descriptor. When selected, original characters 19 and 20 left unchanged; When polled, characters 19 and 20 are truncated.	R/W
LN	Hex	0 to 15	LEGEND NUMBER Two digit number 0 to 99 (decimal) written to the last two characters of the descriptor. Numbers greater than 99 give two spaces. When polled, returns zero if final two characters are non-numeric.	R/W
MV*	Hex	0 to 15	MEASURED VALUE Integer F99A to 4665 (-10 to +110% of span) 0000 = Scale zero 3FFF = Full scale A000 = Invalid data 9FFF = Over range data A001 = Under range data	R/W
NA	Hex		NUMBER OF ALARMS Always returns 4	Read only
OH	Decimal	N/A	SCALE HIGH VALUE AND CHART SPAN HIGH	R/W
OL	Decimal	N/A	SCALE LOW VALUE AND CHART SPAN LOW	R/W
PV*	Decimal	N/A	PROCESS VARIABLE Measured value scaled in engineering units. Poll: -9999. = Under range or invalid 9999. = Over range Select: Values outside the current range by more than 10% which are sent to the recorder are represented as being over or under range as appropriate.	R/W
SA	Hex	0 to 15	SPAN ADJUST POINT Select: ignored; Poll: always returns 3FFF	R/W
SH	Hex	0 to 15	SHUNT VALUE Shunt value in Ohms between 1 and 65535 (Hex 0001 to FFFF) Values > 65535 = 0	R/W
ST	Hex	0 to 15	CHANNEL STATUS 0 = Configured and measuring analogue input 1 = Configured and reading comms input 2 = Channel off 5 = Input hardware capabilities exceeded 9 = Channel under range A = Channel over range B = Channel invalid 3, 4, 6, 7, 8 and C to F not used	Read only

* MV and PV may be written-to only when linearisation type (CF bits 8 to 11) is set to COMMS

Table 3.4.1a (cont.) Input channel mnemonics (sheet 2)

3.4.1 CHANNEL MNEMONICS (Cont.)

Output channels

Mnemonic	Format	Bits	Definition	Permission wrt host
CF	Hex	0	CHANNEL FLAGS SCALE PRINT FLAG Select: Set scale type A to off (=0) or Automatic (=1) Poll: 0 = Scale type A off; 1 = Automatic or customised	R/W
		1	Not used	
		2	TRACE SKIP FLAG Select: 0 = trace on; 1 = trace off Poll: 0 = trace on or conditional; 1 = trace off	R/W
		3	INTERPOLATION ENABLE (1 = on; 0 = off)	R/W
		4 to 13 14 & 15	Not used. Always return 0 OUTPUT TYPE 0 = Off; 1 = Voltage o/p; 2 = Current o/p	R/W
DH	Decimal	N/A	OUTPUT LOW LIMIT (in engineering units) For constant channel, also sets chart span low to this value	R/W
DL	Decimal	N/A	OUTPUT HIGH LIMIT (in engineering units) For constant channel, also sets chart span high to this value	R/W
EU	Hex	0 to 3	PRINT ZONE Selects print zone A Integer 0 to 9. When polled, returns 0. 0 = 0 to 100% 5 = 50 to 100% 1 = 0 to 75% 6 = 0 to 25% 2 = 25 to 100% 7 = 25 to 50% 3 = 0 to 50% 8 = 50 to 75% 4 = 25 to 75% 9 = 75 to 100%	Should the print area be more than 1% different from any of these zone limits, zone 0 is returned. E.G. 24 to 76% would be returned as zone 4, but 23 to 76% would be returned as zone 0.
		4 to 11	Not used.	
		12 to 15	Not used. Always returns 8	
LG	Character		LEGEND STRING 18-character string mapped onto the first 18 characters of the channel descriptor. When selected, the last two characters of the descriptor remain unchanged. When polled they are removed.	R/W
LN	Hex	0 to 15	LEGEND NUMBER When selected, a two digit number 0 to 99 (decimal) written to the last two characters of the descriptor. Numbers greater than 99 give two spaces. When polled, returns zero if final two characters are non-numeric.	R/W
MV	Hex	0 to 15	MEASURED OUTPUT VALUE Integer F99A to 4665 (-10 to +110% of span) 0000 = Scale zero 3FFF = Full scale A000 = Invalid data 9FFF = Over range data A001 = Under range data	Read only

Table 3.4.1b Output channel mnemonics (sheet 1)

3.4.1 CHANNEL MNEMONICS (Cont.)

Mnemonic	Format	Bits	Definition	Permission wrt host
NA	Hex		NUMBER OF ALARMS Always returns 4	Read only
OC	Decimal	N/A	CONSTANT OUTPUT VALUE (in engineering units)	R/W
OF	Decimal	N/A	OFFSET VALUE	R/W
OH	Decimal	N/A	SOURCE SPAN HIGH VALUE (in engineering units) Also sets chart span high to the same value. Ignored and returns 0 for constant channels.	R/W
OL	Decimal	N/A	SOURCE SPAN LOW VALUE (in engineering units) Also sets chart span low to the same value. Ignored and returns 0 for constant channels.	R/W
OS	Hex	0 & 1	OUTPUT SOURCE CONFIGURATION SOURCE TYPE. 0 = Input channel; 1 = Derived channel; 2 = Constant	R/W
		2 to 8	SOURCE CHANNEL NUMBER..... Integer 1 to 96 (Hex 0001 TO 0060) Ignored and returns 0 if Constant.	R/W
		9 to 12	OUTPUT CHANNEL DECIMAL PLACE..... 0 to F valid for source channel. Only 0 to 4 valid for constant	R/W
		13 & 14	ERROR DRIVE 0 = Drive off; 1 = Drive high; 2 = Drive low	R/W
		15	Not used	
PV	Decimal	N/A	PROCESS VARIABLE (OUTPUT VALUE) Measured output value scaled in engineering units. Poll: -9999. = Under range or invalid 9999. = Over range	Read only
SA	Hex	0 to 15	SPAN ADJUST POINT Ignored; Always returns 3FFF	R/W
ST	Hex	0 to 15	CHANNEL STATUS 0 = Configured and operating analogue output 2 = Channel off 5 = Output hardware capabilities exceeded 9 = Under range A = Over range 1, 3, 4, 6 to 8 and B to F not used.	Read only
ZA	Hex	0 to 15	ZERO ADJUST POINT Ignored; Always returns 0	R/W

0 = XXXXX.	4 = X.XXXXX	8 = XXXXX.XXX	C = Scientific
1 = XXXX.X	5 = XXXXXXXX.	9 = XXXX.XXXX	D = Time
2 = XXX.XX	6 = XXXXXXXX.X	A = XXX.XXXXX	E = Date
3 = XX.XXX	7 = XXXXXXX.XX	B = XX.XXXXX	F = Elapsed time

Table 3.4.1b (cont.) Output channel mnemonics (sheet 2)

3.4.1 CHANNEL MNEMONICS (Cont.)

Derived channels

Mnemonic	Format	Bits	Definition	Permission wrt host
CF	Hex	0	CHANNEL FLAGS SCALE PRINT FLAG	R/W
		1	LEGEND PRINT ENABLE FLAG	R/W
		2	TRACE SKIP FLAG	R/W
		3	INTERPOLATION ENABLE (1 = on; 0 = off)	R/W
		4 to 15	Not used	
EU	Hex	0 to 3	ENGINEERING UNITS AND PRINT ZONE PRINT ZONE A Integer 0 to 9. When polled, returns 0. 0 = 0 to 100% 5 = 50 to 100% 1 = 0 to 75% 6 = 0 to 25% 2 = 25 to 100% 7 = 25 to 50% 3 = 0 to 50% 8 = 50 to 75% 4 = 25 to 75% 9 = 75 to 100%	R/W
		4 to 7	Not used	
		8 to 11	CHANNEL ENGINEERING UNITS	
		12 to 15	Not used. Always returns 0	
			<div style="border: 1px solid black; padding: 5px; width: fit-content;"> Software version 3.17 onwards. Should the print area be more than 1% different from any of these zone limits, zone 0 is returned. E.G. 24 to 76% would be returned as zone 4, but 23 to 76% would be returned as zone 0. </div>	
LN	Hex	0 to 15	LEGEND NUMBER	R/W
			Two digit number 0 to 99 (decimal) written to the last two characters of the descriptor. Numbers greater than 99 give two spaces. When polled, returns zero if final two characters are non-numeric.	
MV	Hex	0 to 15	MEASURED VALUE	R/W
			Integer F99A to 4665 (-10 to +110% of span) 0000 = Scale zero 3FFF = Full scale A000 = Invalid data 9FFF = Over range data A001 = Under range data	
NA	Hex		NUMBER OF ALARMS	Read only
			Always returns 4	
OH	Decimal	N/A	SCALE HIGH VALUE AND CHART SPAN HIGH	R/W
OL	Decimal	N/A	SCALE LOW VALUE AND CHART SPAN LOW	R/W
PV*	Decimal	N/A	PROCESS VARIABLE	Read only
			Measured value scaled in engineering units. Poll: -9999. = Under range or invalid 9999. = Over range	
ST	Hex	0 to 15	CHANNEL STATUS	Read only
			2 = Channel off 7 = Configured and recording derived function 8 = Derived function becoming erroneous in real time 0, 1, 3 to 6 and 9 to F not used.	

Table 3.4.1c Derived channel parameters

3.4.2 Alarm mnemonics

NOTES...

1. Alarm parameters are accessible only with a logical unit address (U) of zero.
 2. Before a new alarm can be set-up a "get alarm" mnemonic (GA) must be transmitted. Refer to section 3.5.11 for GA definition.
 3. After all the data for the alarm has been set-up, an "enter alarm" mnemonic (EA) must be transmitted to cause the data to be written into the recorder's data base.
 4. When an EA is received the checks listed below are carried out, and if the update is valid, the data is loaded into the recorder's data base and an ACK is returned. If the update is not valid, the buffer content is discarded and a NAK is returned.
 5. In order to access current alarms, a 'get alarm' command (GA) must be transmitted in order to copy the relevant alarm's parameters into the alarm buffer. Refer to section 3.5.11 for GA definition. After any update to the alarm an EA must be transmitted, to write the new data to the recorder's data base
 6. When using inverted scales it is important to note that the alarm sense (e.g. rising or falling) is related to the input signal, but the alarm setpoints are related to the scale.
-

ALARM BUFFER VALIDATION CHECKS.

- a) Deviation out alarms Hysteresis < twice deviation value

3.4.2 ALARM MNEMONICS (Cont.)

Mnemonic	Format	Bits	Definition	Permission wrt host	
A1	Hex	0 to 7	ALARM PACKET 1 Not used; always return 0	R/W	
		8 to 9	ALARM TYPE	R/W	
			0 = Not used 1 = Absolute 2 = Deviation 3 = Rate-of-change		
		10 to 14	HYSTERESIS (Absolute and deviation alarms only) (Fixed point 0.0 to 9.5% span) {Bit 14 is a binary fraction (logic 1 ≡ 1/2)}	R/W	
A2	Hex	0	ALARM PACKET 2 SKIP FLAG	R/W	
			Poll: 0 = Alarm latched, unlatched or process; 1 = Alarm off		
		1	SENSE FLAG	R/W	
			For absolute alarms, 1 = high; 0 = low For deviation alarms, 1 = in; 0 = out For rate-of-change alarms, 1 = rise; 0 = fall		
		2 to 7	Not used - always return 0 when polled	R/W	
		8	ALARM FLAG (1 = alarm; 0 = no alarm)	Read only	
		9	ACKNOWLEDGE FLAG	Read only	
			0 = not acknowledged; 1 = acknowledged		
		10	NEEDS ACKNOWLEDGE FLAG	Read only	
			0 = Does not need acknowledgement; 1 = Needs acknowledgement		
A3	Hex	11 to 13	RATE-OF-CHANGE ALARM PERIOD	R/W	
			0 = 1 second 4 = 10 minutes 1 = 10 seconds 5 = 30 minutes 2 = 30 seconds 6 = 1 hour 3 = 1 minute		
		14 to 15	Not used - always return 0 when polled	R/W	
		0 to 15	ALARM PACKET 3 (Absolute and Deviation alarms only) SET POINT as a proportion of channel scale..... Scale low = 0000; scale high = 3FFF	R/W	
		A4	Hex	ALARM PACKET 4 (Deviation and Rate-of-change alarms)	
		0 to 15		DEVIATION VALUE OR CHANGE VALUE	R/W
				(as a proportion of channel scale) 0000 = 0.0; 3FFF = Scale high - Scale low	

Table 3.4.2 Alarm mnemonics

Note: Because the setpoint is a proportion of full scale, any change in scale will result in a change in the absolute value of any setpoints, deviation values or rates-of-change set up in A3 and A4 above

3.4.3 Instrument mnemonics

Notes

1. Access to instrument parameters may be gained only through the use of logical unit address 0
2. A valid (0 to F) channel address must be present, even though it is not used when accessing instrument parameters.

Mnemonic	Format	Bits	Definition	Permission wrt host																																							
BN	Character		Poll: First eight characters of operator message 1. Select: Sends eight characters (pads with spaces)	R/W																																							
CD	Character		Not used - returns eight strings of 18 spaces each	R/W																																							
CE	Character		Not used - returns 13 strings of five spaces	R/W																																							
CS	Hex	0 to 7	CHART SPEED Chart speed A. Integer 0 to B	R/W																																							
		8 to 15	Chart speed B. Integer 0 to B	R/W																																							
<table border="1"> <thead> <tr> <th>Integer</th> <th>mm/hr</th> <th>in/hr</th> </tr> </thead> <tbody> <tr><td>0</td><td>Off</td><td>Off</td></tr> <tr><td>1</td><td>5</td><td>0.25</td></tr> <tr><td>2</td><td>10</td><td>0.5</td></tr> <tr><td>3</td><td>20</td><td>1</td></tr> <tr><td>4</td><td>30</td><td>2</td></tr> <tr><td>5</td><td>60</td><td>4</td></tr> <tr><td>6</td><td>120</td><td>6</td></tr> <tr><td>7</td><td>300</td><td>10</td></tr> <tr><td>8</td><td>600</td><td>25</td></tr> <tr><td>9</td><td>1200</td><td>50</td></tr> <tr><td>A</td><td>1500</td><td>5</td></tr> <tr><td>B</td><td>User</td><td>User</td></tr> </tbody> </table>					Integer	mm/hr	in/hr	0	Off	Off	1	5	0.25	2	10	0.5	3	20	1	4	30	2	5	60	4	6	120	6	7	300	10	8	600	25	9	1200	50	A	1500	5	B	User	User
Integer	mm/hr	in/hr																																									
0	Off	Off																																									
1	5	0.25																																									
2	10	0.5																																									
3	20	1																																									
4	30	2																																									
5	60	4																																									
6	120	6																																									
7	300	10																																									
8	600	25																																									
9	1200	50																																									
A	1500	5																																									
B	User	User																																									
DY	Hex	0 to 15	DAY NUMBER Integer 1 to 31 (Hex 0001 to 001F)	R/W																																							
ER	Hex	0 to 15	COMMS ERROR STATUS (Cleared by reading. ER holds only the last comms. error code.) Integer 0 to 43 (Hex 0 to 2B) 00 No error 01 Invalid mnemonic 02 Checksum error 03 Read attempted on write-only parameter 04 Write attempted on read-only parameter 05 Invalid unit/channel address combination 06 No free alarms available 07 Access attempted on invalid alarm record. 08 Invalid alarm number for this channel. 09 Printer buffer not empty 0A Invalid time parameter 0B Invalid instrument ID string length. 0C Invalid batch number string length. 0D Invalid channel parameter buffer 0E Invalid channel descriptor string length. 0F Invalid channel engineering units string length	Read only																																							

Table 3.4.3a Instrument mnemonics (sheet 1)

3.4.3 INSTRUMENT MNEMONICS (Cont.)

Mnemonic	Format	Bits	Definition	Permission wrt host
ER	Hex		COMMS ERROR STATUS (Cont.) 10 Program mode active - cannot disable 11 Print line too long 12 Invalid colour select code 13 Linearisation table too long 14 Linearisation table too short 15 Invalid slot configuration string length 16 Invalid slot configuration 17 Invalid print mode 18 Invalid paper divisions 19 Invalid chart speed parameter 1A Invalid log interval - mode 2 1B Invalid log interval - mode 3 1C Parity error 1D Receive overrun error 1E Framing error 1F Invalid data format 20 Channel number out of range 21 Alarm number out of range 22 Channel not configured for external input 23 Data base update pending 24 Protected area of RAM is not write enabled 25 Printer off line 26 Printer on line 27 Printer busy 28 No log in mode 1 2A No resettable channels 2B Input not defined for current function	
HR	Hex	0 to 15	HOURS Integer 0 to 23 (Hex 0000 to 0017)	R/W
ID	Character		INSTRUMENT DESCRIPTOR Not used - always returns 24 spaces if polled	R/W
IF	Hex	0 1 2 3 4 to 15	INSTRUMENT FLAGS 0 Not used - always returns 0 if polled 1 CURRENT CHART SPEED FLAG (Ref. CS) 0 = Speed A; 1 = Speed B 2 CHART SPEED UNITS FLAG (0 = mm/hr; 1 = in/hr) 3 DATE FORMAT (0 = dd/mm/yy; 1 = mm/dd/yy) 4 to 15 Not used - always return 0 when polled	R/W R/W R/W
II	Hex	0 to 15	INSTRUMENT IDENTIFIER Always returns >4001	Read only
IS	Hex	0 1 2 to 15	INSTRUMENT STATUS 0 INSTRUMENT ALARM FLAG (1 = active) 1 PRINTER ON/OFF LINE (1 = Off; 0 = On) 2 to 15 Not used - always return 0	Read only Read only Read only
L1 to L3	Character		LINEARISATION TABLES Not used. Return 'Empty' when polled.	R/W

Table 3.4.3a (Cont.) Instrument mnemonics (sheet 2)

3.4.3 INSTRUMENT MNEMONICS (Cont.)

Mnemonic	Format	Bits	Definition	Permission wrt host																
MI	Hex	0 to 15	MINUTES Integer 0 to 59 (Hex 0000 to 003B)	R/W																
MO (Not M0)	Hex	0 to 15	MONTH Integer 0 to 12 (Hex 0000 to 000C)	R/W																
M2	Hex	0 to 15	MODE 2 LOG INTERVAL (0 = Off)	R/W																
			Interval in minutes between timed logs (log interval A) Integer 0 to 6039 (Hex 0000 to 1797)																	
M3	Hex	0 to 15	MODE 3 LOG INTERVAL (0 = Off)	R/W																
			Integer 0 to 36234 (Hex 0000 to 8D8A) Poll: Log interval A in 10s of seconds Select: Truncates to a multiple of minutes																	
PM	Hex	0 to 1 2 to 15	PRINT MODE	R/W																
			Print mode (1 = trend; 2 = Text; 3 = Text only) Not used - always return 0 when polled.																	
PT	Character		TEXT TO BE PRINTED	Write only																
			Up to 100 printable characters printed in black. Colour underlining is possible using 'n' embedded in the text string, to select colour n (see table below). Up to 10 colour selections can be embedded in one string. USE OF THE EXCLAMATION MARK (!) IS NOT ALLOWED IN A TEXT STRING EXCEPT TO DEFINE THE UNDERLINE COLOUR																	
			<table border="1"> <thead> <tr> <th>n</th> <th>Underline colour</th> <th>n</th> <th>Underline colour</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Red</td> <td>4</td> <td>Purple</td> </tr> <tr> <td>2</td> <td>Orange</td> <td>5</td> <td>Blue</td> </tr> <tr> <td>3</td> <td>Green</td> <td>6</td> <td>None</td> </tr> </tbody> </table>	n	Underline colour	n	Underline colour	1	Red	4	Purple	2	Orange	5	Blue	3	Green	6	None	
n	Underline colour	n	Underline colour																	
1	Red	4	Purple																	
2	Orange	5	Blue																	
3	Green	6	None																	
RJ	Hex	0 1 to 15	REMOTE CJ (Software versions 3.12 onwards)	R/W																
			REMOTE CJ MODE 0 = Single remote CJ used for all channels (see 'T0' below) 1 = Remote CJ channel for each input board (see 'T1 to TC' below) Not used																	
SC	Character		SLOT CONFIGURATION	Read only																
			When polled, gives the type of board fitted at each address as: 0 (8 or 16 channel input), 6 (Relay output), D (8-channel output), E (4-channel output) or F (Empty) Byte 1 contains the type for address 1; byte 2 the type for address 2 etc. Byte 8 always returns 'F' (Empty)																	
SE	Hex	0 to 15	SECONDS Integer 0 to 59 (Hex 0000 to 003B)	Read only																
			MAY NOT BE WRITTEN TO																	
T0 (T zero)	Hex	0 1 to 2 3 4 to 10 11 to 15	SINGLE REMOTE CJ CONFIG (Software versions 3.12 onwards) ... Used only when RJ above is set to 0 REMOTE CJ ENABLE 0 = Disable remote CJ channel 1 = Enable remote CJ channel REMOTE CJ UNITS 0 = Degrees Celsius 1 = Degrees Fahrenheit 2 = Kelvins 3 = Rankine CHANNEL TYPE 0 Input channel; 1 = Derived channel REMOTE CJ CHANNEL ADDRESS See table 3.4.3b Not used	R/W																

Table 3.4.3a (Cont.) Instrument mnemonics (sheet 3)

3.4.3 INSTRUMENT MNEMONICS (Cont.)

Mnemonic	Format	Bits	Definition	Permission wrt host
T1 to TC	Hex	0 to 15	MULTIPLE REMOTE CJ CONFIG (S/W versions 3.12 onwards) Used only when RJ above is set to 1 Note Tn = Remote CJ config. for input board with address n where n = 1 to C for 250mm recorders n = 1 to 6 for 180mm multipoint recorders n = 1 to 4 for 180/250 mm continuous recorders.	R/W
VN	Character		VERSION NUMBER OF EMULATED 4001 SOFTWARE Returns: 7.1LE0 (no maths pack) 7.1LE2 (Maths pack level 1 fitted) 7.1LE3 (Maths pack level 2 fitted)	Read only
XE	Hex	0 to 3	XMODEM ERROR REPORTING 0 Transfer OK, no errors 1 Restore failed completely. File incompatible or comms transfer failure. Previous configuration unaffected. 2 Restore failed on data. Some records ignored, but restore operation mostly successful. 3 Restore failed on transfer - new configuration undefined. 16 Save operation had no reply from comms and timed out 32 Save operation failed before transfer was completed.	Read only
XT	Hex	0 to 1 2 to 15	ENTER XMODEM MODE 0 = as standby; 1 = as receiver; 2 = as sender Not used	Write only
YR	Hex	0 to 15	YEAR Offset from year 1900 Integer 88 to 188 (Hex 0058 to 00BC)	R/W

Table 3.4.3a (Cont.) Instrument mnemonics (sheet 3)

Input channel addresses			
All recorders	Multipoint recorders only	250 mm multipoint recorders only	
00 = Reserved	21 = Channel 33	31 = Channel 49	49 = Channel 73
01 = Channel 1	22 = Channel 34	32 = Channel 50	4A = Channel 74
02 = Channel 2	23 = Channel 35	33 = Channel 51	4B = Channel 75
03 = Channel 3	24 = Channel 36	34 = Channel 52	4C = Channel 76
04 = Channel 4	25 = Channel 37	35 = Channel 53	4D = Channel 77
05 = Channel 5	26 = Channel 38	36 = Channel 54	4E = Channel 78
06 = Channel 6	27 = Channel 39	37 = Channel 55	4F = Channel 79
07 = Channel 7	28 = Channel 40	38 = Channel 56	50 = Channel 80
08 = Channel 8	29 = Channel 41	39 = Channel 57	51 = Channel 81
09 = Channel 9	2A = Channel 42	3A = Channel 58	52 = Channel 82
0A = Channel 10	2B = Channel 43	3B = Channel 59	53 = Channel 83
0B = Channel 11	2C = Channel 44	3C = Channel 60	54 = Channel 84
0C = Channel 12	2D = Channel 45	3D = Channel 61	55 = Channel 85
0D = Channel 13	2E = Channel 46	3E = Channel 62	56 = Channel 86
0E = Channel 14	2F = Channel 47	3F = Channel 63	57 = Channel 87
0F = Channel 15	30 = Channel 48	40 = Channel 64	58 = Channel 88
10 = Channel 16		41 = Channel 65	59 = Channel 89
11 = Channel 17		42 = Channel 66	5A = Channel 90
12 = Channel 18		43 = Channel 67	5B = Channel 91
13 = Channel 19		44 = Channel 68	5C = Channel 92
14 = Channel 20		45 = Channel 69	5D = Channel 93
15 = Channel 21		46 = Channel 70	5E = Channel 94
16 = Channel 22		47 = Channel 71	5F = Channel 95
17 = Channel 23		48 = Channel 72	60 = Channel 96
18 = Channel 24			
19 = Channel 25			
1A = Channel 26			
1B = Channel 27			
1C = Channel 28			
1D = Channel 29			
1E = Channel 30			
1F = Channel 31			
20 = Channel 32			

Table 3.4.3b Remote CJ Channel addressing (Mnemonics T0 and T1 to TC - table 3.4.3a)

3.5 COMMAND MNEMONICS

There are a number of mnemonics that do not directly access parameters, but which cause the serial link to perform some action. These mnemonics are write-only i.e. they must be sent as a selection message and cannot be polled.

3.5.1 Alarm acknowledge (AA)

On receipt of this mnemonic, all alarms requiring acknowledgement are acknowledged.

3.5.2 Printer on (CG)

If the printer is off line receipt of this mnemonic will turn it on and return an ACK. If the printer is already on, a NAK is returned.

3.5.3 Chart halt (CH)

No action taken. Always returns ACK

3.5.4 Printer off (CO)

If the printer is on-line, then receipt of this mnemonic causes the it to be switched off-line and an ACK is returned. If the printer is already off, a NAK is returned.

3.5.5 Chart Wind (CW)

Receipt of this command whilst the printer is off-line, causes the chart to wind forward 16 cm. at maximum speed. CW commands received whilst the printer is on-line return a NAK.

3.5.6 Data Dump (DD)

If the printer is on-line, then receipt of this command causes log1 to be printed on the chart and an ACK to be returned. If the printer is off-line then no action is taken and a NAK is returned.

3.5.7 Disable program mode (DP)

If the recorder is not in configuration mode, then the sending of 'DP' causes entry to the configuration mode to be inhibited and an ACK to be returned. If the recorder is in configuration mode, then no action is taken and a NAK is returned. Should the operator attempt to enter configuration, when it has thus been disabled, the message "Configuration access disabled by comms" will appear.

3.5.8 Enter alarm data (EA)

When alarm data is being written to the recorder, the new data is held in a temporary storage area (buffer), which is re-initialised each time new alarm data is entered. On receipt of the 'EA' mnemonic, the data in the buffer is checked, and if valid, it is written to the recorder's data base and an ACK is returned. If the data is not valid, then the buffer content is discarded and a NAK is returned.

3.5.9 Enter channel data (EC)

When channel parameters are being written to (selected), the new data is held in a temporary storage area (buffer), which is re-initialised each time a new channel is written to. On receipt of the 'EC' mnemonic, the data in the buffer is checked, and if valid, it is written to the recorder's data base and an ACK is returned. If the data is not valid, then the buffer content is discarded and a NAK is returned.

3.5.10 Enable program mode (EP)

The sending of 'EP' causes the configuration menu to be enabled regardless of its existing state. ACK is always returned.

3.5.11 Get indicated alarm data (GA)

Allows the channel number and alarm number required to be defined, as follows:

NO MATHS PACK FITTED

Bits	Definition
0 to 5	Alarm number (integer 1 to 4)
6 to 7	Not used
8 to 15	Channel number Integer 1 to 30 (Hex 0001 to 001E) = channels 1 to 30 respectively Integer 63 to 131 (Hex 003F to 0083) = channels 31 to 99 respectively

MATHS PACK FITTED

Bits	Definition
0 to 5	Alarm number (integer 1 to 4)
6 to 7	Not used
8 to 15	Channel number Integer 1 to 30 (Hex 0001 to 001E) = Measuring channels 1 to 30 respectively Integer 31 to 62 (Hex 001F to 003E) = Derived channels 1 to 32 respectively Integer 63 to 131 (Hex 003F to 0083) = Measuring channels 31 to 99 respectively Integer 132 to 198 (Hex 0084 to 00C6) = Derived channels 33 to 99 respectively

3.5.12 Get free alarm (GF)

Implemented only on model 4001

3.5.13 Chart rewind (CR)

Implemented only on model 4001

3.6 PARAMETER SCROLLING

This is a feature which allows a number of parameters to be read one after the other on receipt of an ACK after each poll. The parameters are divided into two types: Block Command and Scroll List.

3.6.1 Block parameters

If the previous command parameter was a Block Command Parameter, the recorder automatically increments the channel address within the logical unit, and transmits the value of the same mnemonic as last time, but for the new channel. The channel address is continuously incremented until it reaches its maximum value for the particular LU / CA entry combination, and is then reset to the minimum, and so on, as follows:

LU	CA sequence	LU	CA sequence
1	0, 1, 2, 3, 0, 1, 2,	8	0, 1, 0, 1, 0.....
1	4, 5, 6, 4, 5, 6,	8	2, 3, 4, 5, 6, 2, 3, 4,....
1	7, 8, 9, A, B, C, D, E, F, 7, 8, 9,....	9	0, 1, 2, 3, 4, 5, 6, 7, 0, 1, 2,
2	0, 1, 2, 3, 0, 1, 2,	9	8, 9, A, B, C, D, E, F, 8, 9, A,
2	4, 5, 6, 4, 5, 6,	A	0, 1, 2, 3, 4, 5, 6, 7, 0, 1, 2,
2	7, 8, 9, A, B, C, D, E, F, 7, 8, 9,	A	8, 9, A, B, C, D, E, F, 8, 9, A,
3	0, 1, 2, 3, 0, 1, 2,	B	0, 1, 2, 3, 4, 5, 6, 7, 0, 1, 2,
3	4, 5, 6, 4, 5, 6,	B	8, 9, A, B, C, D, E, F, 8, 9, A,
3	7, 8, 9, A, B, C, D, E, F, 7, 8, 9,	C	0, 1, 2, 3, 4, 5, 0, 1, 2,
4	0, 1, 2, 3, 0, 1, 2,	C	6, 7, 6, 7, 6,
4	4, 5, 6, 4, 5, 6,	C	8, 9, A, B, C, D, E, F, 8, 9, A,
4	7, 8, 9, A, B, C, D, E, F, 7, 8, 9,	D	0, 1, 2, 3, 4, 5, 6, 7, 0, 1, 2,
5	0, 1, 2, 3, 0, 1, 2,	D	8, 9, A, B, C, D, E, F, 8, 9, A,
5	4, 5, 6, 4, 5, 6,	E	0, 1, 2, 3, 4, 5, 6, 7, 0, 1, 2,
5	7, 8, 9, A, B, C, D, E, F, 7, 8, 9,	E	8, 9, A, 8, 9, A,
6	0, 1, 2, 3, 0, 1, 2,	F	0, 1, 2, 3, 4, 5, 6, 7, 0, 1, 2,
6	4, 5, 6, 4, 5, 6,		
7	0, 1, 2, 3, 0, 1, 2,		
7	4, 5, 6, 4, 5, 6,		

Table 3.6.1 Block parameter scroll sequences

3.6.2 Scroll parameters

Alarm and Instrument parameters are all scroll parameters. This means that when an ACK is received, the next parameter in the lists below is accessed.

ALARM PARAMETERS

The alarms are scrolled in order A1, A2, A3, A4, A1, A2 —etc

INSTRUMENT PARAMETERS

The instrument parameters are scrolled in order:

SC, IF, PM, PD*, IS, ER, HR, MI, SE, DY, MO, YR, BN, CD*, CE*, II, VN, ID, CS, M2, M3, L1 to L3, J1* to J5*, RJ†, T0†, T1† to Tn†, SC, IF, ... , etc.

* These parameters are not emulated by the recorder. If selected, they are ignored, if polled, they return zero.

† These parameters appear only with software versions 3.12 onwards.

In 'Tn' n = Hex C for 250mm multipoint recorders, n = 6 for 180mm recorders and n = 4 for continuous recorders.

3.7 CHARACTER SET

CHARACTER	CONTROL KEY	BINARY CODE	HEX CODE	DECIMAL CODE
NUL		000 0000	00	0
SOH (Start of heading)	A	000 0001	01	1
STX (Start of text) *	B	000 0010	02	2
ETX (End of text) *	C	000 0011	03	3
EOT (End of transmission) *	D	000 0100	04	4
ENQ (Enquiry) *	E	000 0101	05	5
ACK (Acknowledge) *	F	000 0110	06	6
BEL (Bell)	G	000 0111	07	7
BS (Backspace)	H	000 1000	08	8
HT (Horizontal tab)	I	000 1001	09	9
LF (Line feed)	J	000 1010	0A	10
VT (Vertical tab)	K	000 1011	0B	11
FF (Form feed)	L	000 1100	0C	12
CR (Carriage return)	M	000 1101	0D	13
SO (Shift out)	N	000 1101	0E	14
SI (Shift in)	O	000 1111	0F	15
DLE (Data link escape)	P	001 0000	10	16
DC1 {Device control 1 (XON)} *	Q	001 0001	11	17
DC2 (Device control 2)	R	001 0010	12	18
DC3 {Device control 3 (XOFF)} *	S	001 0011	13	19
DC4 {Device control 4 (stop)}	T	001 0100	14	20
NAK (Negative acknowledge) *	U	001 0101	15	21
SYN (Synchronous idle)	V	001 0110	16	22
ETB (End of transmission block)	W	001 0111	17	23
CAN (Cancel)	X	001 1000	18	24
EM (End of medium)	Y	001 1001	19	25
SUB (Substitute)	Z	001 1010	1A	26
ESC (Escape)		001 1011	1B	27
FS (File separator)		001 1100	1C	28
GS (Group separator)		001 1101	1D	29
RS (Record separator)		001 1110	1E	30
US (Unit separator)		001 1111	1F	31
(Space)		010 0000	20	32
! (Exclamation mark)		010 0001	21	33
" (Double quote)		010 0010	22	34
# (Hash) (£ sign - ISO 7)		010 0011	23	35
\$ {Dollar (or £ sign)}		010 0100	24	36
% (Per cent)		010 0101	25	37
& (Ampersand)		010 0110	26	38
` (Closing single quote)		010 0111	27	39
((Opening round bracket)		010 1000	28	40
) (Closing round bracket)		010 1001	29	41
* (Asterisk)		010 1010	2A	42
+ (Plus sign)		010 1011	2B	43
, (Comma)		010 1100	2C	44
- (Minus sign)		010 1101	2D	45
. {Full stop (period)}		001 1110	2E	46
/ (Oblique)		010 1111	2F	47

* Only those control characters marked with an asterisk are correctly interpreted by the instrument. The use of other control codes may lead to unrecoverable errors.

Table 3.7 Character set: Sheet 1 Hex 00 to 2F

3.7 CHARACTER SET (Cont.)

CHARACTER	BINARY CODE	HEX CODE	DECIMAL CODE	
0	011 0000	30	48	
1	011 0001	31	49	
2	011 0010	32	50	
3	011 0011	33	51	
4	011 0100	34	52	
5	011 0101	35	53	
6	011 0110	36	54	
7	011 0111	37	55	
8	011 1000	38	56	
9	011 1001	39	57	
:	(colon)	011 1010	3A	58
;	semi-colon)	011 1011	3B	59
<	(less than)	011 1100	3C	60
=	(equals)	011 1101	3D	61
>	(greater than)	011 1110	3E	62
?	(question mark)	011 1111	3F	63
@	100 0000	40	64	
A	100 0001	41	65	
B	100 0010	42	66	
C	100 0011	43	67	
D	100 0100	44	68	
E	100 0101	45	69	
F	100 0110	46	70	
G	100 0111	47	71	
H	100 1000	48	72	
I	100 1001	49	73	
J	100 1010	4A	74	
K	100 1011	4B	75	
L	100 1100	4C	76	
M	100 1101	4D	77	
N	100 1110	4E	78	
O	100 1111	4F	79	
P	101 0000	50	80	
Q	101 0001	51	81	
R	101 0010	52	82	
S	101 0011	53	83	
T	101 0100	54	84	
U	101 0101	55	85	
V	101 0110	56	86	
W	101 0111	57	87	
X	101 1000	58	88	
Y	101 1001	59	89	
Z	101 1010	5A	90	
[(opening square bracket)	101 1011	5B	91
\	(back slash)	101 1100	5C	92
]	(closing square bracket)	101 1101	5D	93
^	(circumflex)	101 1110	5E	94
_	(Underline)	101 1111	5F	95

Table 3.7 (cont.) Sheet 2: Hex 30 to 5F

3.7 CHARACTER SET (Cont.)

CHARACTER	BINARY CODE	HEX CODE	DECIMAL CODE
' opening quote	110 0000	60	96
a	110 0001	61	97
b	110 0010	62	98
c	110 0011	63	99
d	110 0100	64	100
e	110 0101	65	101
f	110 0110	66	102
g	110 0111	67	103
h	110 1000	68	104
i	110 1001	69	105
j	110 1010	6A	106
k	110 1011	6B	107
l	110 1100	6C	108
m	110 1101	6D	109
n	110 1110	6E	110
o	110 1111	6F	111
p	111 0000	70	112
q	111 0001	71	113
r	111 0010	72	114
s	111 0011	73	115
t	111 0100	74	116
u	111 0101	75	117
v	111 0110	76	118
w	111 0111	77	119
x	111 1000	78	120
y	111 1001	79	121
z	111 1010	7A	122
{ (opening curly bracket)	111 1011	7B	123
(vertical line)	111 1100	7C	124
} (closing curly bracket)	111 1101	7D	125
~ (tilde)	111 1110	7E	126
Not printed	111 1111	7F	127

Table 3.7 (Cont.) Sheet 3: Hex 60 to 7F.

3.7 CHARACTER SET (Cont.)

CHARACTER	BINARY CODE	HEX CODE	DECIMAL CODE
Ç	1000 0000	80	128
ü	1000 0001	81	129
é	1000 0010	82	130
â	1000 0011	83	131
ä	1000 0100	84	132
à	1000 0101	85	133
â	1000 0110	86	134
ç	1000 0111	87	135
ê	1000 1000	88	136
ë	1000 1001	89	137
è	1000 1010	8A	138
ï	1000 1011	8B	139
î	1000 1100	8C	140
ì	1000 1101	8D	141
Ä	1000 1110	8E	142
À	1000 1111	8F	143
É	1001 0000	90	144
æ	1001 0001	91	145
Æ	1001 0010	92	146
ô	1001 0011	93	147
ö	1001 0100	94	148
ò	1001 0101	95	149
û	1001 0110	96	150
ù	1001 0111	97	151
ÿ	1001 1000	98	152
õ	1001 1001	99	153
ü	1001 1010	9A	154
ø	1001 1011	9B	155
£	1001 1100	9C	156
¥	1001 1101	9D	157
ƒ	1001 1110	9E	158
ƒ	1001 1111	9F	159
á	1010 0000	A0	160
í	1010 0001	A1	161
ó	1010 0010	A2	162
ú	1010 0011	A3	163
ñ	1010 0100	A4	164
Ñ	1010 0101	A5	165
â	1010 0110	A6	166
o	1010 0111	A7	167
ç	1010 1000	A8	168
+	1010 1001	A9	169
-	1010 1010	AA	170
•	1010 1011	AB	171
•	1010 1100	AC	172
•	1010 1101	AD	173
•	1010 1110	AE	174
•	1010 1111	AF	175

Table 3.7 (Cont.) Sheet 4: Hex 80 to AF

3.7 CHARACTER SET (Cont.)

CHARACTER		BINARY CODE	HEX CODE	DECIMAL CODE
0	(Superscript)	1011 0000	B0	176
1	(Superscript)	1011 0001	B1	177
2	(Superscript)	1011 0010	B2	178
3	(Superscript)	1011 0011	B3	179
4	(Superscript)	1011 0100	B4	180
5	(Superscript)	1011 0101	B5	181
6	(Superscript)	1011 0110	B6	182
7	(Superscript)	1011 0111	B7	183
8	(Superscript)	1011 1000	B8	184
9	(Superscript)	1011 1001	B9	185
0	(Subscript)	1011 1010	BA	186
1	(Subscript)	1011 1011	BB	187
2	(Subscript)	1011 1100	BC	188
3	(Subscript)	1011 1101	BD	189
4	(Subscript)	1011 1110	BE	190
5	(Subscript)	1011 1111	BF	191
6	(Subscript)	1100 0000	C0	192
7	(Subscript)	1100 0001	C1	193
8	(Subscript)	1100 0010	C2	194
9	(Subscript)	1100 0011	C3	195
0		1100 0100	C4	196
1		1100 0101	C5	197
2		1100 0110	C6	198
3		1100 0111	C7	199
4		1100 1000	C8	200
5		1100 1001	C9	201
6		1100 1010	CA	202
7		1100 1011	CB	203
8		1100 1100	CC	204
9		1100 1101	CD	205
	Not printed	1100 1110	CE	206
	Not printed	1100 1111	CF	207
	Not printed	1101 0000	D0	208
	Not printed	1101 0001	D1	209
	Not printed	1101 0010	D2	210
	Not printed	1101 0011	D3	211
	Not printed	1101 0100	D4	212
	Not printed	1101 0101	D5	213
	Not printed	1101 0110	D6	214
	Not printed	1101 0111	D7	215
	Not printed	1101 1000	D8	216
	↓	1101 1001	D9	217
	⚠ {Bell (alarm) symbol}	1101 1010	DA	218
	█	1101 1011	DB	219
	←	1101 1100	DC	220
	→	1101 1110	DD	221
	↑	1101 1101	DE	222
	↓	1101 1111	DF	223

Table 3.7 (Cont.) Sheet 5: Hex B0 to E2

3.7 CHARACTER SET (Cont.)

CHARACTER	BINARY CODE	HEX CODE	DECIMAL CODE
α	1110 0000	E0	224
β	1110 0001	E1	225
Γ	1110 0010	E2	226
π	1110 0011	E3	227
Σ	1110 0100	E4	228
σ	1110 0101	E5	229
μ	1110 0110	E6	230
τ	1110 0111	E7	231
ϕ	1110 1000	E8	232
θ	1110 1001	E9	233
Ω	1110 1010	EA	234
δ	1110 1011	EB	235
∞	1110 1100	EC	236
\boxminus	1110 1101	ED	237
E	1110 1110	EE	238
\cup	1110 1111	EF	239
\equiv	1111 0000	F0	240
\pm	1111 0001	F1	241
\geq	1111 0010	F2	242
\leq	1111 0011	F3	243
- (Minus)	1111 0100	F4	244
+ (Plus)	1111 0101	F5	245
\div (Divide)	1111 0110	F6	246
\approx	1111 0111	F7	247
\ast	1111 1000	F8	248
\cdot	1111 1001	F9	249
\cdot	1111 1010	FA	250
\downarrow	1111 1011	FB	251
h	1111 1100	FC	252
e	1111 1101	FD	253
▪	1111 1110	FE	254
Not printed	1111 1111	FF	255

Table 3.7 (Concluded) Sheet 6: Hex E0 to FF

3.8 APPLICATION NOTES

3.8.1 Message timing

The recorder can receive a message as a continuous byte stream (i.e. the bytes in a message may be end to end).

3.8.2 Command mnemonics

These mnemonics cause the serial link to perform some action. Command mnemonics which control the chart have the same priority as the operator (i.e. last input from either source overrides previous inputs).

3.8.3 Channel selection

It is not possible to write directly to the recorder data base because of the interdependence of parameters. For this reason, the characters are held in a buffer until an 'EC' command mnemonic is received.

As each parameter is received it is checked, and if it is valid, an ACK is returned and the data is stored in the buffer. (If the data is not valid, a NAK is returned and the data is discarded.) When the EC mnemonic is received the contents of the buffer are checked, and if the data is all valid, the contents of the buffer are stored in the recorder data base, and an ACK is returned. If the data is not valid, a NAK is returned, the data is discarded and an error flag set in 'ER' (See Instrument Mnemonics in section 3.4.3, above).

Note: It is not possible for the user to read the buffer, either before or after the EC mnemonic.

3.8.4 Alarm selection / polling

There is a single buffer through which alarms can be accessed. The relevant alarm is read into the buffer from the data base as the result of a command mnemonic 'GA'. This buffer can then be written to or read, via the instrument address (U = 0). When writing to the buffer, the data is stored until a command mnemonic (EA) is received, as described below.

SELECTION

As each parameter is received it is checked, and if it is valid, an ACK is returned and the data is stored in the buffer. (If the data is not valid, a NAK is returned and the data is discarded.) When the EA mnemonic is received the contents of the buffer are checked, and if the data is all valid, the contents of the buffer are stored in the recorder data base, and an ACK is returned. If the data is not valid, a NAK is returned and the data is discarded. The alarm buffer is marked as 'invalid' and must be refilled before it can again be accessed. A NAK is returned if an attempt is made to read or write to the buffer before it is refilled.

3.8.5 Printed text

If text to be printed is sent via the 'PT' mnemonic (section 3.4.3) it is placed in the instrument's demand message queue, and treated as a standard demand message. If there is insufficient space in the queue, a NAK is returned.

3.8.6 Special characters

ASCII MODE

The printing control characters (table 3.1.2) may be used only as control characters (i.e. they may not be used as a part of a text string). The ASCII control characters (e.g. STX) may not be used at all in ASCII mode.

ANSI MODE

The ASCII control characters may be used only in their correct positions (i.e. they may not be used as a part of a text string).

Notes

1. The special characters shown in table 3.7 sheets 3, 4 and 5, above, require the use of eight data bits, and both the recorder and the host must be configured as such.
 2. Model 4001 characters which are not available with current recorders and vice-versa, are treated as an underline symbol (_).
-

3.8.7 Multi-parameter data packets

When a parameter which contains a number of different individual items (e.g. channel flags CF - see table 3.4.1) then it is not possible to change only a single item within the parameter; the whole word must be written with the required data for each bit.

When one or more bits in a multi-parameter mnemonic are READ-ONLY, or not used, those bits are ignored. No error flag is set in 'ER'.

3.8.8 Digital input channels

These types of channel cannot be written to using this communications protocol. If an attempt is made to do so, a NAK is returned and code 05 is set into 'ER'.

The process value (PV) for digital channels may be polled (read), with the response 0.0 if the input is open and 1.0 if the input is closed.

The measured value (MV) for digital channels may also be polled (read), with the response 0000 if the input is open and 0001 if the input is closed.

3.8.9 Floating point overflow

Maths channel PVs, scales, alarm setpoints etc. may exceed the floating point range (9999) of the 4001 emulation protocol. In such a case, the value 9999 (with appropriate sign) is returned.

4 GOULD MODICON MODBUS PROTOCOL

When connected to a host computer the recorder acts as a slave Modbus device. The unit address (1 to 247) being set up as a part of the recorder's communications configuration. Only a limited number of function codes have been implemented (ref. Modbus protocol manual) and these are listed in section 4.3

4.1 CHANNEL ADDRESSING

The channel 1 address listed in table 4.3 is the base address at which channel 1 may be accessed.

Note: Addressing starts at zero, whilst channel numbers start at 1

Example: to read a digital input at channel 23, the required address passed with the code 01 would be 22

If an alarm is set for an input or derived channel, the associated alarm parameters can be read using code 03

Example: To read the set point of absolute alarm 1 on channel 8, the required address passed with code 03 should be 1257 (1250 = channel 1; 1251 = channel 2 etc.).

The interpretation of alarm parameters (A1 to A4 and SP1 to SP4 in table 4.3) depends on alarm type as follows:

ALARM TYPE	PARAMETER	DEFINITION
Absolute	A1 to A4	Not used
Absolute	SP1 to SP4	Setpoint values
Deviation	A1 to A4	Deviation values
Deviation	SP1 to SP4	Setpoint values
Rate	A1 to A4	Rate value
Rate	SP1 to SP4	Period value (secs)
Digital	A1 to A4	Not used
Digital	SP1 to SP4	0000 = Open; FFFF = closed

Table 4.1 Alarm parameter interpretation

Note: Any request to read a nonexistent setpoint value will result in the value 0000 being returned. This should not be taken to mean that the setpoint is at 0.000

4.2 READING ANALOGUE VALUES

4.2.1 16-bit format

The values read are in the range 0000 to FFFF. To obtain the scaled relative value, the following calculation must be carried out:

$$\text{Scaled value} = \left(\frac{\text{High range} - \text{Low range}}{\text{FFFF}} \times \text{Analogue measurement} \right) + \text{low range}$$

where the analogue measurement is in hex.

In the event of a hardware error or under-range value, the value is forced to scale zero. Should the analogue value be over range, the scaled value is forced to scale high.

4.2 READING ANALOGUE VALUES (Cont.)

4.2.2 32-bit format

Values read from service code 03 addresses based at:

7250 (Analogue channel scale low value)
 7750 (Analogue channel scale high value)
 8250 (Derived channel scale low value)
 8750 (Derived channel scale high value)

and values read from service code 04 addresses based at:

1500 (Analogue channel value)
 2000 (Derived channel value)

are in 32-bit IEEE floating point format. Each value resides in two consecutive 16-bit registers transmitted most significant byte first. Two registers per channel must be requested, and the required address increases by two per channel number, for example:

Analogue channel 1: Code04; address 1500
 Analogue channel 2: Code 04; address 1502
 or generally:
 Analogue channel N: code 04; address 1500 + 2(N-1)

Example 1 Read channel 05

(0x- means the two characters following the 'x' are in hexadecimal)

```
<slave address><code><register addr high><register addr low><n° of registers high>
<n° of registers low><CRC high><CRC low>
```

Specifically, to read analogue channel 05 from slave address 2:

```
<0x02><0x04><0x05><0xE4><0x00><0x02><CRC high><CRC low>
```

To which the reply should be:

```
<slave address><code><byte count most significant> <next byte> <next byte>
<least significant > byte
```

Specifically for channel 5 having a value of 1.123 (0x3F8FBE76 in 32-bit IEEE format)

```
<0x02><0x04><0x04><0x3F><0x8F><0xBE><0x76>
```

TOTALISER VALUES

To read a totaliser value, use the derived channel copy facility to import the totaliser value into a derived channel, and read this derived channel using service code 04 (base address 2000). The returned value will be in 32-bit IEEE float as described above.

4.3 FUNCTION CODES

CODE	FUNCTION	RECORDER ACTION	CHANNEL 1 ADDRESS (DECIMAL)
01	Read coil status	Digital input state (true = >0.5)	0
02	Digital read input status	Digital input state (true = < 0.5)	0
		I/O alarm 1 status	250
		I/O alarm 2 status	500
		I/O alarm 3 status	750
		I/O alarm 4 status	1000
		Derived alarm 1 status	1250
		Derived alarm 2 status	1500
		Derived alarm 3 status	1750
		Derived alarm 4 status	2000
		03	Read holding register
I/O channel A1 (Table 4.1)	250		
I/O channel A2 (Table 4.1)	500		
I/O channel A3 (Table 4.1)	750		
I/O channel A4 (Table 4.1)	1000		
I/O channel SP1 (Table 4.1)	1250		
I/O channel SP2 (Table 4.1)	1500		
I/O channel SP3 (Table 4.1)	1750		
I/O channel SP4 (Table 4.1)	2000		
Derived channel A1 (Table 4.1)	2250		
Reserved (always returns 0000)	2500		
Derived channel A2 (Table 4.1)	2750		
Reserved (always returns 0000)	3000		
Derived channel A3 (Table 4.1)	3250		
Reserved (always returns 0000)	3500		
Derived channel A4 (Table 4.1)	3750		
Reserved (always returns 0000)	4000		
Derived channel SP1 (Table 4.1)	4250		
Reserved (always returns 0000)	4500		
Derived channel SP2 (Table 4.1)	4750		
Reserved (always returns 0000)	5000		
Derived channel SP3 (Table 4.1)	5250		
Reserved (always returns 0000)	5500		
Derived channel SP4 (Table 4.1)	5750		
Reserved (always returns 0000)	6000		
I/O channel status (read only) (flags - see code 04)	6250		
Derived channel status (read only) (flags - see code 04)	6500		
Instrument status (read only) (flags - see code 07)	6750		
Analogue real channel scale low value (32-bit)	7250		
Analogue real channel scale high value (32-bit)	7750		
Derived channel scale low value (32-bit)	8250		
Derived channel scale high value (32-bit)	8750		

Table 4.3 Modbus implementation channel addresses (Sheet 1: codes 01 to 03)

4.3 FUNCTION CODES (Cont.)

CODE	FUNCTION	RECORDER ACTION	CHANNEL 1 ADDRESS (DECIMAL)
04	Read input register	Analogue input/output value0 I/O channel status250 No bits set: Channel OK Bit 0 set: Channel off Bit 1 set: Over range Bit 2 set: Under range Bit 3 set: Hardware error / bad PV Bit 4 set: Ranging error / no data Bit 5 set: Overflow Bits 6 to 15: Always 0. Derived channel value500 Reserved (returns 0000)750 Derived channel status 1000 (Bits 0 to 15 as for I/O channel status above) Instrument status (flags - code 7) 1250 Analogue real channel value (32-bit) 1500 Derived channel value (32-bit) 2000	
05	Force single coil	Sets digital input state for comms channel0 0 = 0.000; 1 = 1.000	
06	Preset single register	Preset holding register As code 03 (Presets values for comms channels only) (Base addresses 7250, 7750, 8250 and 8750 cannot be preset)	
07	Read exception status	Read instrument status Bit 0: System error Bit 1: Writing system failure Bit 2: Paper out (250 mm non-graphics recorders only) Bits 3 to 7 Always 0	
08	Loopback test	Diagnostic code 0 (Echoes message as sent)	
15	Force multiple coil	Sets digital input code for comms channels in address range.0 0 = 0.000 1 = 1.000	
16	Preset multiple registers	Preset holding register for each channel in address range. As code 03 (Presets values for comms channels only) (Base addresses 7250, 7750, 8250 and 8750 cannot be preset)	
65	Enter XMODEM mode	Holds 1 byte of data specifying which mode to enter 0 = standby; 1 = Receiver; 2 = Sender	
66	Report XMODEM error	Returns 1 byte of data as follows: 0: Transfer OK - no errors 1: Restore failed completely File was incompatible or comms failed to transfer the file, Original configuration unchanged. 2: Restore failed on data. Some records ignored, but transfer mostly successful. 3: Restore failed on transfer Some config. transferred before failure. New configuration undefined 16: Save had no reply from comms and timed out 32: Save failed before transfer completed	

Table 4.3 Modbus implementation channel addresses (Sheet 2)

4.3 FUNCTION CODES (Cont.)

CODE	FUNCTION	RECORDER ACTION	CHANNEL 1 ADDRESS (DECIMAL)
EXCEPTION RESPONSES			
01	Illegal function	Unsupported or illegal Modbus function	0
02	Illegal data address	Data address out of range for instrument config	0
		Attempt to preset input value of non comms channel	
		Invalid configuration data	
03	Illegal data	Data value out of range for function	
06	Illegal busy	Configuration transfer in progress via another port so unable to action function	

Table 4.3 Modbus implementation channel addresses (Sheet 3)

5 XMODEM TRANSFER

XMODEM transfers take place between a host computer and a single instrument using MODBUS or 4001 protocol. The transfer is used to save or restore recorder configurations. The transfer procedure is as follows

1. Place any other instruments on the communications link into standby mode.
2. Set the required recorder to sender or receiver mode as appropriate.
3. Send or receive file at host.
4. 10 seconds after completion, host communications is restored to normal use.

Notes:

1. 10 seconds of inactivity on the communications link, at any point in the procedure, will cause the host communications to return to normal use for instruments in standby mode.
2. XMODEM transfer is not possible with graphics recorders or graphics display units.

6 LIST OF EFFECTIVE PAGES

This (issue 13) manual consists of the following pages at their stated issues:

Page 1	Issue 13 Nov 98	Page 25	Issue 13 Nov 98
Page 2	Issue 13 Nov 98	Page 26	Issue 13 Nov 98
Page 3	Issue 13 Nov 98	Page 27	Issue 13 Nov 98
Page 4	Issue 13 Nov 98	Page 28	Issue 13 Nov 98
Page 5	Issue 13 Nov 98	Page 29	Issue 13 Nov 98
Page 6	Issue 11 Dec 97	Page 30	Issue 13 Nov 98
Page 7	Issue 11 Dec 97	Page 31	Issue 13 Nov 98
Page 8	Issue 11 Dec 97	Page 32	Issue 13 Nov 98
Page 9	Issue 11 Dec 97	Page 33	Issue 13 Nov 98
Page 10	Issue 11 Dec 97	Page 34	Issue 13 Nov 98
Page 11	Issue 13 Nov 98	Page 35	Issue 13 Nov 98
Page 12	Issue 13 Nov 98	Page 36	Issue 13 Nov 98
Page 13	Issue 13 Nov 98	Page 37	Issue 13 Nov 98
Page 14	Issue 13 Nov 98	Page 38	Issue 13 Nov 98
Page 15	Issue 13 Nov 98	Page 39	Issue 13 Nov 98
Page 16	Issue 13 Nov 98	Page 40	Issue 13 Nov 98
Page 17	Issue 13 Nov 98	Page 41	Issue 13 Nov 98
Page 18	Issue 13 Nov 98	Page 42	Issue 13 Nov 98
Page 19	Issue 13 Nov 98	Page 43	Issue 13 Nov 98
Page 20	Issue 13 Nov 98	Page 44	Issue 13 Nov 98
Page 21	Issue 13 Nov 98	Page 45	Issue 13 Nov 98
Page 22	Issue 13 Nov 98	Page 46	Issue 13 Nov 98
Page 23	Issue 13 Nov 98	Page 47	Issue 13 Nov 98
Page 24	Issue 13 Nov 98	Page 48	Issue 13 Nov 98

Index

Symbols

4001 ANSI protocol	
Description	15
Selection	14
4001 ASCII protocol	
Description	16
Selection	14

A

Alarm mnemonics	25
Application notes	40

B

Baud rate setting	14
-------------------------	----

C

Channel mnemonics	
Derived channels	24
Input channels	20
Output channels	22
Character set	34
Circuit board links	13
Command mnemonics	31
Configuration	
Circuit board links	13
Hardware	14
Software	14

D

Data bits	14
Data formats	17

F

Function codes	44 to 46
----------------------	----------

H

Hardware handshake	14
--------------------------	----

I

Installation	
Electrical	9
Mechanical	4
180 mm recorders	7
250mm continuous-trace recorders	6
Instrument mnemonics	27

M

Modbus protocol	42
-----------------------	----

P

Parameter	
Addressing	17
Alarm	25
Derived channel	24
Input channel	20
Instrument	27
Mnemonics overview	18
Output channel	22
Scrolling order	33
Parity setting	14
Protocol selection	14

R

Reading analogue values	
16-bit	42
32-bit	43
Reading totaliser values	43
RS232/RS422/RS485 selection	
Isolated version	9
Original version	5

S

Software Handshake	14
Stop bits	14

T

Termination and biasing	11
-------------------------------	----

X

XMODEM transfer	46
XON-XOFF	14

Inter-Company sales and service locations

Australia

Eurotherm Pty. Limited.
Unit 10,
40 Brookhollow Avenue,
Baulkham Hills,
NSW 2153

Telephone: 61 2 9634 8444
Fax: 61 2 9634 8555
Email: vincelen@eurotherm.com.au
or: vince.lendrum@eurotherm.com.au

Austria

Eurotherm Meß-und Regeltechnik GmbH
Geiereckstraße 18/1,
A1110 Wien,

Telephone: 43 1 798 76 01
Fax: 43 1 798 76 05

Belgium

Eurotherm BV,
Herentalsebaan 71-75,
B 2100 Deurne
Antwerpen

Telephone: 32 3 322 3870
Fax: 32 3 321 7363

Denmark

Eurotherm Danmark A/S
Finsensvej 86,
DK 2000 Fredriksberg,

Telephone: 45 38 871622
Fax: 45 38 872124

Finland

Eurotherm Finland,
Auragaten 12A,
FIN-20100 Åbo

Telephone: 358 22 50 60 30/1
Fax: 358 22 50 32 01

France

Eurotherm Mesures SA,
15, Avenue de Norvège,
ZA de Courtaboeuf,
BP225
F - 91942 Les Ulis, CEDEX

Telephone: 33 1 69 18 51 00
Fax: 33 1 69 18 51 99

Germany

Eurotherm Meßdatentechnik GmbH
Ottostraße 1,
D-65549 Limburg a.d.Lahn

Tel: 49 64 31 9173 0
Fax: 49 64 31 9173 33

Great Britain

Eurotherm Recorders Limited,
Dominion Way,
Worthing,
West Sussex BN14 8QL

Telephone: 01 903 205222
Telex: 877296 CHESEL G
Fax: 01 903 203767

Email: Sales@recorders.eurotherm.co.uk
or: Support@recorders.eurotherm.co.uk
Web: <http://www.eurotherm.co.uk>

Hong Kong

Eurotherm Limited,
Unit D, 18/F Gee Chang Hong Centre,
65, Wong Chuk Hang Road,
Aberdeen.

Telephone: 852 2873 3826
Telex: 69257EIFEL HX
Fax: 852 2870 0148

India

Eurotherm Del India Limited,
152, Developed Plots Estate,
Chennai 600 096,

Telephone: 91 44 4961129
Fax: 91 44 4961831

Italy

Eurotherm SpA,
Via XXIV Maggio,
I-22070 Guanzate,
Como.

Telephone: 39 031 975111
Fax: 39 031 977512

Japan

Eurotherm Business Unit,
Nemic Lambda KK,
Denpa Building,
1-11-15 Higashi Gotanda,
Shinagawa,
Tokyo 141-0022

Telephone: 81 3 3447 6441
Fax: 81 3 3447 6442

Korea

Eurotherm Korea Limited,
J- Building
402-3
Poongnab-Dong,
Songpa-Ku
Seoul, 138-040

Telephone: 82 2 2478 8507
Fax: 82 2 488 8508

Netherlands

Eurotherm BV,
Genielaan 4,
2404CH Alphen aan den Rijn,
The Netherlands

Telephone: 31 172 411 752
Fax: 31 172 417 260

Norway

Eurotherm A/S,
Post Boks 650,
N - 1411 Kolbotn,
Norway,

Telephone: 47 66 803330
Fax: 47 66 803331

Spain

Eurotherm España SA,
Pol. Ind. De Alcobendas,
Calle de la Granja 74,
28108 Alcobendas,
Madrid.

Telephone: 34 91 661 60 01
Fax: 34 91 661 90 93

Sweden

Eurotherm AB,
Lundavägen 143,
S-21224 Malmö.

Telephone: 46 40 38 45 00
Fax: 46 40 38 45 45

Switzerland

Eurotherm Produkte (Schweiz) AG,
Schwerzistraße, 20,
CH-8807 Freienbach.

Telephone: 41 55 415 44 00
Fax: 41 55 415 44 15

United States of America

Eurotherm Recorders Inc.
One Pheasant Run,
Newtown Industrial Commons,
Newtown PA 18940.

Telephone: 1 215 968 0660
Fax: 1 215 968 0662
Web: <http://www.eurotherm.com/chessell>
e-mail: sales@recorders.eurotherm.com



**EUROTHERM
CHESELL**

EUROTHERM RECORDERS LIMITED

A member of the Eurotherm PLC Group of Companies
Dominion Way, Worthing, West Sussex, BN14 8QL
Telephone: 01 903 205222. Telex: 877296. Facsimile: 01 903 203767
e-mail: Sales@recorders.eurotherm.co.uk
e-mail: Support@recorders.eurotherm.co.uk
Website: <http://www.eurotherm.co.uk>

